



How To Replace Padded Foam Liner Into 7P104 Or 7P105 Bucket

1. Remove old liner completely. You may have to use a blade to cut the liner out from under the leather rim.
2. Clean inside of bucket surface. Use a small grinder or sand paper to rough up the inside of the bucket. This will help the adhesive to stick to the bucket.
3. Spray inside bucket with commercial grade adhesive such as 3M Super 77 Multipurpose Permanent Spray Adhesive Glue (Available at most hardware stores and Amazon).
4. Starting with the new liner rolled up, align it in the middle of the back of the bucket, roll it out around the bucket. It will be a little longer than needed, this will be trimmed after next step.
5. Holding the new liner in place, use a roller to apply pressure all the way around the bucket to ensure that the liner is in good contact with the bucket.
6. You will need to trim a little bit of the excess as we make the liners a little bit oversize.
7. Allow to dry as instructed on adhesive used.